


## *BD03* original bar-graph driver



amperage ..... 20 amp nominal  
monitoring ..... net amps service battery  
power terminals .... none, cable through  
display terminals .. 1x6, + 1x12 way connector  
replacement ..... **B3**.  
available ..... new only

fitted to

**Sealine** .... 290 Am, 310 St,  
328 So, 365 Sb

### Notes

Bar-driver measures magnetic field around power cable, and has infinite overload.

Provides display of net amps into / out of the service battery.

The unit also supplies voltages to the digital voltmeter display in switch panel, and power feed from both battery banks to the link start relay.