

## S1 SEALINE shunt and driver module EIPS51STT

**S1** comprises shunt 12302103  
driver 12441106

**SA1** adaptor 12302204

These are fitted to most SEALINE models from 1998 to 2012.  
2012 the blue labelled shunt was introduced, see S2

The sensor is located on the service battery main positive terminal, and is fitted on the adaptor.

The driver module is located behind the switch panel by the ammeter and voltmeter gauges.

The shunt and driver are supplied as a pair, and are not available separately.

If you return both units, we are happy to check them for you.

### Note

The driver module has white and green output wires.

GREEN, ammeter with 30 amp scale

WHITE, ammeter with 50 amp scale

