

SG02 shore / generator relay manual

- operation manual or automatic
- input live & neutral from shore & generator
- output AC supply to switch panel
- termination screw via relay terminals
- option terminals status via 6 way connector
- replacement **SG2** manual operation
- available new only

fitted to

390, 410, 420, 450

Manual operation **SG2**

Unit connected boat AC power to either shore supply, or generator via remote switch on main switch panel.

Supply source signal to panel will illuminate shore or gen window, indicating supply source in use.

